



Quantum Timber Finishes
Product Data Sheet

Power Clean



Description:

Power Clean is ideal for removing treatments, sealers and weathered oil based finishes. For removing tannins from the timber we suggest Quantum Sap-Strip. Use on any timber surface where the removal of old oil coatings or treatments is necessary. Power Clean is not a paint or varnish stripper, you would need Qstrip for that application.

How to Apply:

It is advisable to wet surrounding areas and plants before starting. Apply undiluted to a wet surface using a garden spray, brush or roller. Allow Power Clean to remain wet on the surface for approximately 10 minutes. Do not let the product dry on the surface. Test to see if the coating has lifted, scrub with a stiff bristle broom. Using a strong jet of water or pressure wash, rinse from the surface of the timber. Repeat if necessary. Follow this with a solution of Quantum Dex Prep to neutralise the timber and rid the surface of any darkening which may occur in the cleaning process. eg 1 litre Dex Prep to 1 litre of water.

Cedar may darken when using Power Clean.

Warning:

Failure to thoroughly remove the cleaning solution may result in timber discolouring under clear finishes.

Coverage:

Approximately 10 square metres per litre.

Safety Data:

**POISON: NOT TO BE TAKEN.
KEEP OUT OF REACH OF CHILDREN.
AVOID CONTACT WITH SKIN AND EYES.**

First Aid:

If swallowed do not induce vomiting and drink large amounts of water. If splashed in the eyes, hold eye open and flush with water for 15 minutes. Use soap and water to wash the skin if splashed on skin areas.

If poisoning occurs, contact a doctor or the Poisons Information Centre 131126.

Ph: 03 9776 8831

Fax: 03 9782 4417

Freecall: 1800 053 018

quantum@qtf.com.au